


STREETLIGHT PHOTOMETRIC TEST REPORT

Test:U:230.07V I:0.3945A P:90.512W PF:0.9973 Freq:50.00Hz Lamp Flux:12757.5x1 lm		
NAME: PELICAN FORT - A9	TYPE:POLE MOUNTED SYSTEMS	WEIGHT:6.57Kg
SPEC.:5700K, LUMILED, 80 CRI	DIM.: Ø634 x 618	SERIAL No.:INT/2023/06/66
MFR.: K-LITE	SUR.:	Shielding Angle:

DATA OF LAMP		PHOTOMETRIC DATA			Eff: 110.88 lm/W
MODEL	KL-6799	I _{max} (cd)	5989	η _{street_up} (%)	0.0
NOMINAL POWER(W)	100	LOR(%)	78.7	η _{street_down} (%)	59.2
RATED VOLTAGE(V)	230	TOTAL FLUX(lm)	10036	η _{house_up} (%)	0.1
NOMINAL FLUX(lm)	12757.5	MAXIMUM @ (C, γ)	50,50.0	η _{house_down} (%)	19.3
LAMPS INSIDE	1	η _{up} (%)	0.1	76 FLASHAREA(m ²)	0.00100
TEST VOLTAGE(V)	230	η _{down} (%)	78.5	SLI	18.096



C Range: 0 - 360DEG
C Interval: 10.0DEG
Test Speed: HIGH
Temperature: 25.6DEG
Operators: K-LITE
Test Date: 19 June 2023

γ Range: 0 - 180DEG
γ Interval: 1.0DEG
Test System: EVERFINE GO-R5000_V2 SYSTEM V2.00.417
Humidity: 55.7%
Test Distance: 1.944m [K=1.0000]
Remarks: