K-LITE Micro LED

MICROLED are compact IP67 LED fittings suitable for down light, Wall recessed and walkover for both indoor & outdoor applications. Small dimension with flush mounting installation. It is equipped with a screwless round front ring in STAIN-LESS STEEL with Symmetrical & Asymmetrical. These fixtures are perfect for creating very defined effects of accent light. On request, these luminaires are also available in Red, Green, Blue and Amber.

Product Description

- Luminaire body and screwless front ring made from solid billet of 316 grade stainless steel.
- Silicone seal gasket ensures IP67 rating.
- · Toughened glass of 4mm thickness.
- · Clear polycarbonate optical lens.
- Luminaire hard wired with 2 x 0.5mm² cable of 0.5 metre length.
- Supplied with mounting sleeve for preparing recessed opening in ground or wall.
- · Non integral constant current power supply.
- Ordering guide: KL-4085-CCT (Colour Temperature)
- · Available CCT: 2700K, 4000K, 5700K.
- Options: Red / Green / Blue / Amber (On Request).



Product Benefits

- · High luminous efficiency at reduced wattage.
- Compact luminaire provides distinctive lighting effects for wall architecture & accent lighting.
- Sustainable LED technology offers durability and optimal light output with low power consumption.

Area of Application

Walk ways, Facades, Landscapes, Architectural facade elements.

Accessory

- $\bullet\,$ Supplied with IP67 rated connector for a secure connection to the network.
- $\bullet\,$ ABS Plastic outer costing for easy installation.


Symmetrical Asymmetrical

Driver for 1W Luminaire

ID	Wattage	Driver Output
8242	1W	(3-5)V, 300mA
8243	3-5W	(8-12)V, 300mA
8244	4-8W	(12-24)V, 300mA
8245	8-12W	(24-42)V, 300mA

Supplied with IP67 connector.

For 4085 suitable driver to be ordered separately



Max: 12 Luminaires. The Individual lamps must be connected in series. Only power up the system once all the lamps have being connected.

K-LITE Micro LED





Technical Specifications

General

ID : 4085 System Wattage : 1W LED

Driver Non-Integral : Constant Current

Input Voltage : 240Vac
Frequency : 50-60 Hz
Operating Voltage : 100-265Vac
Operating Temperature :-15°C~+50°C

Physical

Body & Front Ring : 316 Grade Stainless Steel
Diffuser : Toughened Glass
Mounting Sleeve : Polypropylene Black
Mounting : Wall / Floor - Recess

Light Source

Light Source : NICHIA CRI (Ra) : ≥80

LED Colour Temperature : 2700K / 4000K / 5700K


Optical Performance

Beam Angle : 40°









Note: It is our constant endeavor to upgrade the performance of our products. For the latest technical information, IES files and product updates please refer to the website at www.klite.in

K-LiTE Mini LED

MINILED are compact IP67 LED fittings suitable for down light, Wall recessed and walkover for both indoor & outdoor applications. Small dimension with flush mounting installation. It is equipped with a screwless round front ring in STAIN-LESS STEEL with Symmetrical & Asymmetrical. These fixtures are perfect for creating very defined effects of accent light. On request, these luminaires are also available in Red, Green, Blue and Amber.

Product Description

- Luminaire body and screwless front ring made from solid billet of 316 grade stainless steel.
- Silicone seal gasket ensures IP67 rating.
- · Toughened glass of 4mm thickness.
- Clear polycarbonate optical lens.
- Luminaire hard wired with 2 x 0.5mm² cable of 0.5 metre length.
- Supplied with mounting sleeve for preparing recessed opening in ground or wall.
- · Non integral constant current power supply.
- Ordering guide: KL-4086-CCT (Colour Temperature)
- · Available CCT: 2700K, 4000K, 5700K.
- Options: Red / Green / Blue / Amber (On Request).



Product Benefits

- · High luminous efficiency at reduced wattage.
- Compact luminaire provides distinctive lighting effects for wall architecture & accent lighting.
- Sustainable LED technology offers durability and optimal light output with low power consumption.

Area of Application

Walk ways, Facades, Landscapes, Architectural facade elements.

Accessory

- $\bullet\,$ Supplied with IP67 rated connector for a secure connection to the network.
- ABS Plastic outer costing for easy installation.


Symmetrical Asymmetrical

Driver for 3W Luminaire

8246	3W	(3-5)V, 600mA
8247	9-18W	(9-25)V, 900mA
8248	21-30W	(20-36)V, 900mA

Supplied with IP67 connector.

For 4086 suitable driver to be ordered separately



Max: 12 Luminaires. The Individual lamps must be connected in series. Only power up the system once all the lamps have being connected.

K-LITE Mini LED







Asymmetrical

Technical Specifications General

ID : 4086 System Wattage : 3W LED

Driver Non-Integral : Constant Current Input Voltage : 240Vac

Frequency : 50-60 Hz
Operating Voltage :100-265Vac
Operating Temperature :-15°C~+50°C

Physical

Body & Front Ring : 316 Grade Stainless Steel
Diffuser : Toughened Glass
Mounting Sleeve : Polypropylene Black
Mounting : Wall / Floor - Recess

Light Source

Light Source : NICHIA CRI (Ra) : ≥80

LED Colour Temperature : 2700K / 4000K / 5700K


Optical Performance

Beam Angle : 8°/12°/24°/40°/60°/40°x11°









Note: It is our constant endeavor to upgrade the performance of our products. For the latest technical information, IES files and product updates please refer to the website at www.klite.in