

|               |  |                         |
|---------------|--|-------------------------|
| <b>K-LITE</b> | <b>INTRUSION PROTECTION IP TEST REPORT</b> | Doc. No. KL/LAB/IPT1269 |
|               |  | Rev. No. 00             |

**Product / EUT Details**

|                   |                           |
|-------------------|---------------------------|
| Product Name      | ZEDO ROUND                |
| Product ID        | 2766                      |
| Test Location     | K-LITE Testing Laboratory |
| Report Date       | 06/06/21                  |
| Reference Sl. No. | ZEDO ROUND/269/IPT1269    |

**IP-6X (DUST TEST) – Conforming to IEC 60529**


|                 |   |
|-----------------|---|
| Test Equipment  | Dust proof Apparatus (Refer figure below) |
| Test Protection | Solid Foreign Object                      |
| Category        | 2   |
| Dust Used       | Talcum Powder                             |
| Temperature     | Ambient                                   |
| Test Date       | 06/06/21                                  |
| Test Duration   | 8 Hours – (9:45 am to 5:45 pm)            |
| EUT Condition   | Power OFF                                 |


| Requirement   | Results                             | Remarks |
|---|-------------------------------------|---------|
| No deposit of dust inside the EUT.  | No ingress of dust observed on EUT. | P       |
| P→ Passed (Meets requirement); F→ Failed (Does not meet requirement); NA→ Limits of Performance Not Applicable. |                                     |         |



1.This report refers only to the particular item(s) submitted for testing. The results reported in this report are valid at the time of, and under the stipulated conditions of measurement  
2.This report shall not be reproduced, except in full, unless written permission for the publication of an approved abstract has been obtained from the Director, K-LITE, Chennai-600058

  
**Tested by**  
Balamurugan.S  
Jr. Engineer Illumination – OPTIC LAB

  
**Reviewed by**  
Akram Basha.H  
TL – OPTIC LAB

  
**Witnessed by**  
Premkumar. P  
Head - QC

  
**Approved by**  
Muthukumaran.C.R  
Manager - Design

**Product / EUT Details**

|                   |                           |
|-------------------|---------------------------|
| Product Name      | ZEDO ROUND                |
| Product ID        | 2766                      |
| Test Location     | K-LITE Testing Laboratory |
| Report Date       | 06/06/21                  |
| Reference Sl. No. | ZEDO ROUND/269/IPT1269    |

**IP-X5 (JET PROOF TEST) – Conforming to IEC 60529**

|                             |  |
|-----------------------------|--|
| Test Equipment              | Sharadatronic Jet proof/Rainfall test setup (Refer figure below) |
| Spray                       | 6.3mm nozzle jet   |
| Total water flow rate       | 12.5 Ltr/min.  |
| Distance from Nozzle to EUT | Within 3mtr.   |
| Test Date                   | 06/06/21   |
| Test Duration               | 3 Minutes  |
| EUT Condition               | Power OFF  |

| Requirement   | Results                              | Remarks |
|---|--------------------------------------|---------|
| Water projected by a nozzle against the EUT from any direction shall have no harmful effects.                   | No ingress of water observed on EUT. | P       |
| P→ Passed (Meets requirement); F→ Failed (Does not meet requirement); NA→ Limits of Performance Not Applicable. |                                      |         |



1.This report refers only to the particular item(s) submitted for testing. The results reported in this report are valid at the time of, and under the stipulated conditions of measurement  
2.This report shall not be reproduced, except in full, unless written permission for the publication of an approved abstract has been obtained from the Director, K-LITE, Chennai-600058

  
Tested by

Balamurugan.S  
Jr. Engineer Illumination – OPTIC LAB

  
Reviewed by

Akram Basha.H  
TL – OPTIC LAB

  
Witnessed by

Premkumar. P  
Head - QC

  
Approved by

Muthukumaran.C.R  
Manager - Design