A decorative column light designed with single / double sided light output to provide soft, flat beam light distribution. These luminaries offer shielded glare free illumination on ground surface. Clean Lines and pure form are the underlying elements in this series of column light.

Product Description

- Luminaire body made of rectangular extruded aluminium tube (grade 6063) with die cast aluminium components and non corrosive SS fasteners.
- · Non yellowing UV stabilized clear acrylic diffuser.
- · MS mounting plate with an anchorage unit made out of hot dip galvanised steel for extra guarantee against corrosion.
- · Cable entries for through-wiring of mains supply cable.
- · Integral constant current power supply
- CRI (Ra): ≥80
- Prewired with LED driver and suitable for operating on 240V, 50Hz single phase ac supply.
- Ordering guide: KL-4184-CCT (Colour Temperature)
- Available CCT: 3000K, 4000K, 5700K



















Product Benefits

- · High luminous efficiency at reduced wattage.
- · Elegant, Robust design
- · Dark sky compliant protects pedestrians from glare by preventing spill light above the horizontal plane.
- · Sustainable LED technology offers durability and optimal light output with low power consumption.

Area of Application

Suitable for Private & Public areas, Illuminating Driveways, Pathways, Building surrounds, Entrances, Squares & Gardens, Promenades.


Available Finish











K-LiTE



Technical Specifications

General

ID : 4184 / 4185 : 1 x 24W / 2 x 24W LED System Wattage Driver Integral : Constant Current Input Voltage : 230-240Vac Frequency : 50-60 Hz Operating Voltage : 100-277Vac Operating Temperature :-15°C~+50°C

Physical

Body : Rectangular Extruded

Aluminium Tube with

Die-Cast Aluminium

Diffuser : Clear acrylic : Floor - Surface Mounting Finish : Bamboo / Teak /

Bronze Gold Texture

Light Source

Light Source LED Lumens : NICHIA : 3600 / 7200 lm

CRI (Ra) : ≥80

LED Colour Temperature : 3000K / 4000K / 5700K

Driver

Power Supply : Integral Power Factor : >0.95 THD : <10% Surge Protection : 2.5KV :>85% Efficiency

Optical Performance

Light Distribution : Asymmetrical



























Jado / Duo Jado - Column Light

K-LiTE

A decorative column light designed with single / double sided light output to provide soft, flat beam light distribution. These luminaries offer shielded glare free illumination on ground surface. Clean Lines and pure form are the underlying elements in this series of column light.

Product Description

- Luminaire body made of rectangular extruded aluminium tube (grade 6063) with die cast aluminium components and non corrosive SS fasteners.
- · Non yellowing UV stabilized clear acrylic diffuser.
- MS mounting plate with an anchorage unit made out of hot dip galvanised steel for extra guarantee against corrosion.
- · Cable entries for through-wiring of mains supply cable.
- · Integral constant current power supply
- CRI (Ra): ≥80
- Prewired with LED driver and suitable for operating on 240V, 50Hz single phase ac supply.
- · Ordering guide: KL-4186-CCT (Colour Temperature)
- Available CCT: 3000K, 4000K, 5700K



Product Benefits

- · High luminous efficiency at reduced wattage.
- · Elegant, Robust design
- Dark sky compliant protects pedestrians from glare by preventing spill light above the horizontal plane.
- Sustainable LED technology offers durability and optimal light output with low power consumption.


Area of Application

Suitable for Private & Public areas, Illuminating Driveways, Pathways, Building surrounds, Entrances, Squares & Gardens, Promenades.


Available Finish

Pure polyester powder coated

- · Graphite grey
- · Anthracite grey
- Jet black







Technical Specifications

General

ID : 4186 / 4187 : 1 x 24W / 2 x 24W LED System Wattage Driver Integral : Constant Current Input Voltage : 230-240Vac Frequency : 50-60 Hz Operating Voltage : 100-277Vac

Physical

Operating Temperature

Body : Rectangular Extruded

Aluminium Tube with

Die-Cast Aluminium

:-15°C~+50°C

Diffuser : Clear acrylic : Floor - Surface Mounting

Finish : Graphite Grey / Jet Black

Anthracite Grey

Light Source

Light Source : NICHIA LED Lumens : 3600 / 7200 lm

CRI (Ra) :≥80

LED Colour Temperature : 3000K / 4000K / 5700K

Driver

Power Supply : Integral Power Factor : >0.95 THD : <10% Surge Protection : 2.5KV :>85% Efficiency

Optical Performance

Light Distribution : Asymmetrical



















