

K-LiTE Astral

Our modern heritage post top luminaire combines classic aesthetics. Equipped with high-performance light engines, it delivers superior illumination while optimizing energy efficiency. The robust construction ensures resilience against all weather conditions, promising long-term durability and consistent performance throughout its lifespan. Designed to provide maximum lumens with reduced wattages.

Product Description

- The luminaire comprises of spun aluminium top cover with decorative aluminium knob on top.
- Die cast aluminium base through supporting arms made of extruded aluminium.
- Diffuser placed into the provision formed on the pheriphery of the bottom
- · Non yellowing UV stabilized clear acrylic diffuser.
- · Silicone gasket.
- · Luminaire integrated with 30W / 50W LED.
- · Luminaires suitable for mounting on 76mm OD pipe.
- · Cable entries for through-wiring of mains supply cable
- · Integral constant current power supply
- CRI (Ra): ≥70
- Prewired with LED driver and suitable for operating on 240V, 50Hz single phase ac supply.
- · Ordering guide: KL-5444-CCT (Colour Temperature)
- Available CCT: 3000K, 4000K, 5700K



Product Benefits

- · High luminous efficiency at reduced wattage.
- · Elegant, Functionality
- Dark sky compliant protects pedestrians from glare, in addition to preventing spill light above the horizontal plane.
- Sustainable LED technology offers durability and optimal light output with low power consumption.

Area of Application

Illuminating parks, Gardens, commercial complex, Residential roadways, Walkways, Streetscapes & office complex.

Available Finish

Pure polyester powder coated RAL 9004 Signal black RAL 9007 Grey aluminium RAL 7016 Anthracite grey Graphite grey



K-LiTE Astral





Technical Specifications

General

: 5444 / 4492 (Sym) 4522 / 4521 (Asy) ID : 50W / 30W LED System Wattage Driver Integral : Constant Current Operating Voltage : 100-277Vac Operating Temperature :-15°C~+50°C

Physical

Body : Spun aluminium top cover & Die cast aluminium base : Clear acrylic : Suitable for 76mm OD pipe Diffuser

Mounting Finish

: Powder coated

RAL 9004 Signal black RAL 9007 Grey aluminium RAL 7016 Anthracite grey

Graphite grey

Light Source

Light Source : LUMILEDS / OSRAM CRI (Ra) :>70 LED Colour Temperature : 3000K / 4000K / 5700K

Driver

Power Supply : Integral Input Voltage : 230-240Vac Frequency 50-60Hz Power Factor : >0.95 THD :<10% Surge Protection : 6KV / 4KV :>85% Efficiency

Optical Performance

Optical Distribution : Symmetrical / Type IV











IK05