

K-LiTE Astral

A modern heritage post top luminaire upgraded with high performance light engines. Aesthetically designed sturdy construction ensures a long life against all weather condition, maintaining initial performances through the lifetime of the installation. Designed for highest efficiency in terms of more lumens at reduced wattages.

Product Description

- The luminaire comprises of spun aluminium top cover with decorative aluminium knob on top.
- · Die cast aluminium base through supporting arms made of mild steel.
- Diffuser placed into the provision formed on the pheriphery of the bottom cover
- · Non yellowing UV stabilized clear acrylic diffuser.
- · Silicone gasket.
- Luminaire integrated with 30W / 50W LED.
- · Luminaires suitable for mounting on 76mm OD pipe.
- · Cable entries for through-wiring of mains supply cable
- · Integral constant current power supply
- CRI (Ra): ≥70
- Prewired with LED driver and suitable for operating on 240V, 50Hz single phase ac supply.
- Ordering guide: KL-5444-CCT (Colour Temperature)
- · Available CCT: 3000K, 4000K, 5700K









K05





Product Benefits

- · High luminous efficiency at reduced wattage.
- · Elegant, Functionality
- Dark sky compliant protects pedestrians from glare, in addition to preventing spill light above the horizontal plane.
- Sustainable LED technology offers durability and optimal light output with low power consumption.

Area of Application

Illuminating parks, Gardens, commercial complex, Residential roadways, Walkways, Streetscapes & office complex.

Available Finish

Pure polyester powder coated

- Graphite grey
- · Anthracite grey
- Jet black



K-LiTE Astral





Technical Specifications

General

ID : 4492 System Wattage
Driver Integral
Input Voltage
Frequency
Operating Voltage
Operating Temperature : 30W LED : Constant Current : 230-240Vac

: 50-60Hz : 100-277Vac :-15°C~+50°C

Physical

: Spun aluminium top cover Efficiency Body :>85%

& Die cast aluminium base Diffuser : Clear acrylic

: Suitable for 76mm OD pipe Optical Distribution Mounting Finish : Powder Coated

Graphite Grey / Jet Black

Anthracite Grey

Light Source

Light Source : OSRAM / LUMILED

CRI (Ra) :>70

LED Colour Temperature : 3000K / 4000K / 5700K

Driver

: Integral : >0.90 Power Supply Power Factor THD :<10% Surge Protection : 4KV

Optical Performance

: Symmetrical


















K-LiTE Astral





Technical Specifications

General

: 5444 (Sym) 4522 / 4521 (Asy) : 50W / 30W LED ID System Wattage

Driver Integral : Constant Current Input Voltage : 230-240Vac Frequency Operating Voltage : 50-60Hz : 100-277Vac Operating Temperature :-15°C~+50°C

Physical

Body : Spun aluminium top cover

& Die cast aluminium base Optical Performance

Diffuser : Clear acrylic

: Suitable for 76mm OD pipe Mounting : Powder Coated Finish

Graphite Grey / Jet Black

Anthracite Grey

Light Source

Light Source : OSRAM / LUMILED

CRI (Ra) :>70

LED Colour Temperature : 3000K / 4000K / 5700K

Driver

Efficiency


Power Supply : Integral Power Factor : >0.95 / >0.90 THD :<10% Surge Protection : 6KV / 4KV

Optical Distribution

Type IV

:>85%



















IK05





