K-LiTE Romina

A modern heritage post top luminaire upgraded with high performance light engines. Aesthetically designed sturdy construction ensures a long life against all weather condition, maintaining initial performances through the lifetime of the installation. Designed for highest efficiency in terms of more lumens at reduced wattages.

## **Product Description**

- · The luminaire comprises of spun aluminium top cover.
- · Die cast aluminium base through supporting arms made of mild steel.
- Diffuser placed into the provision formed on the pheriphery of the bottom cover.
- · Non yellowing UV stabilized clear acrylic diffuser.
- · Silicone gasket.
- · Luminaire integrated with 30W / 50W LED.
- · Luminaires suitable for mounting on 76mm OD pipe.
- · Cable entries for through-wiring of mains supply cable
- Integral constant current power supply
- CRI (Ra): ≥70
- Prewired with LED driver and suitable for operating on 240V, 50Hz single phase ac supply.
- Ordering guide: KL-5445-CCT (Colour Temperature)
- · Available CCT: 3000K, 4000K, 5700K



#### **Product Benefits**

- · High luminous efficiency at reduced wattage.
- · Elegant, Functionality
- Dark sky compliant protects pedestrians from glare, in addition to preventing spill light above the horizontal plane.
- Sustainable LED technology offers durability and optimal light output with low power consumption.

### Area of Application

Illuminating parks, Gardens, commercial complex, Residential roadways, Walkways, Streetscapes & office complex.

### Available Finish

Pure polyester powder coated

- Graphite grey
- Anthracite grey
- · Jet black



**K-LiTE** Romina





-Ø400-

# **Technical Specifications**

General

ID : 4493 : 30W LED

System Wattage Driver Integral Input Voltage Frequency : Constant Current : 230-240Vac : 50-60Hz

Operating Voltage
Operating Temperature : 100-277Vac :-15°C~+50°C

Physical

Body : Spun aluminium top cover Efficiency

& Die cast aluminium base

Diffuser : Clear acrylic

Mounting

Finish : Powder Coated

Graphite Grey / Jet Black

Anthracite Grey

: Suitable for 76mm OD pipe Optical Distribution

Light Source Light Source CRI (Ra)

Driver

THD

LED Colour Temperature

: Symmetrical



:>70

: OSRAM / LUMILED

: 3000K / 4000K / 5700K



616















**K-LiTE** Romina





# **Technical Specifications**

General

: 5445 (Sym) 4524 / 4523 (Asy) : 50W / 30W LED ID

System Wattage Driver Integral : Constant Current Input Voltage : 230-240Vac Frequency Operating Voltage : 50-60Hz : 100-277Vac Operating Temperature :-15°C~+50°C

Physical

Body : Spun aluminium top cover

& Die cast aluminium base Optical Performance

Diffuser : Clear acrylic

: Suitable for 76mm OD pipe Mounting : Powder Coated Finish

Graphite Grey / Jet Black

IK05

Anthracite Grey

Light Source

Light Source : OSRAM / LUMILED

CRI (Ra) :>70

LED Colour Temperature : 3000K / 4000K / 5700K

Driver

Power Supply : Integral Power Factor : >0.95 / >0.90 THD :<10% Surge Protection Efficiency : 6KV / 4KV

Optical Distribution : Symmetrical /

Type IV

: >85%















