# K-Lite

This elegant lantern features a translucent diffuser that delivers a soft, glare-free light, creating a comfortable and inviting atmosphere. Its thoughtfully designed, robust construction ensures long-lasting performance, even in harsh weather conditions. With its enduring durability and consistent light output, this lantern maintains its initial quality throughout its lifespan, offering a reliable and stylish lighting solution for any environment.

#### Product Description

- Aluminium housing, integrated with extruded aluminium pipe along with pressure die cast aluminium base through supporting arms made of gravity die cast aluminium.
- Diffuser placed into the provision formed on the pheriphery of the bottom cover.
- Non yellowing UV stabilized translucent acrylic diffuser.
- Low power loss LED driver with 36W LED.
- Suitable for mounting on 50mm OD pipe.
- Cable entries for through-wiring of mains supply cable.
- Integral constant current power supply
- CRI ( Ra) : ≥80
- Prewired with LED driver and suitable for operating on 240V, 50Hz single phase ac supply.
- Ordering guide : KL-5380-CCT (Colour Temperature)
- Available CCT : 2700K, 3000K, 4000K, 5700K



#### Product Benefits

- High luminous efficiency at reduced wattage.
- Elegance, Functionality.
- Environmental friendly, moisture proof, insect free.
- Dark sky compliant protects pedestrians from glare, in addition to preventing spill light above the horizontal plane.
- Sustainable LED technology offers durability and optimal light output with low power consumption.

#### Area of Application

Illuminating parks, Gardens, commercial complex, Pathways in residential buildings & office complex.

#### Available Finish

Pure polyester powder coated RAL 9004 Signal black RAL 9007 Grey aluminium RAL 7016 Anthracite grey Graphite grey



## **K-LITE**

#### Juno Midi






IIM, TRICHY

### **Technical Specifications**

8 (E 🔄 IP65 IK07

| General<br>ID<br>System Wattage<br>Driver Integral<br>Operating Voltage<br>Operating Temperature | : 5380<br>: 36W LED<br>: Constant Current<br>: 100-277Vac<br>: -15°C~+50°C                    | Light Source<br>Light Source<br>CRI (Ra)<br>LED Colour Temperature | : NICHIA<br>: >80<br>: 2700K / 3000K / 4000K<br>5700K |
|--|---|--|---|
|  | . 10 0 100 0  | Driver   |   |
| Physical   |   | Power Supply   | : Integral  |
| Body   | : Extruded aluminium with   | Input Voltage  | : 230-240Vac  |
|  | Spun Aluminium Top  | Frequency  | : 50-60 Hz  |
| Diffuser   | : Translucent Acrylic   | Power Factor   | : >0.95   |
| Mounting   | : Suitable for Mounting   | THD  | : <10%  |
|  | on Ø50mm OD Pipe  | Surge Protection   | : 4KV   |
| Finish   | : Powder coated   | Efficiency   | :>85%   |
|  | RAL 9004 Signal black<br>RAL 9007 Grey aluminium<br>RAL 7016 Anthracite grey<br>Graphite grey | Optical Performance<br>Light Distribution                          | : 120°  |



Note : It is our constant endeavor to upgrade the performance of our products. For the latest technical information, IES files and product updates please refer to the website at www.klite.in