K-LiTE

Linear Wall Washer

Compact & Minimilist linear surface mounted luminaire designed for wall, ceiling & floor mount application. Ideal light distribution serves both wall washing & wall grazing applications.

Product Description

- Luminaire made up of extruded aluminium alloy and flush end caps with silicone gasket
- Equipped to take multiple optics for varied wall grazing & spot light distribution
- Optical compartment closed at the top by a 3mm thick toughened glass screen secured with silicone
- · All external screws used are in A2 stainless steel.
- Mounting bracket with an adjustable feature from 0°-45° facilitate proper aiming of the luminaire at desired angle
- · Wall, ceiling and floor mount options with adjustable brackets
- · Constant voltage non integral power supply
- Supplied with IP67 male and female connectors for easy series connection.
- · Low Voltage at 24V dc assures safety.
- Ordering guide: KL-3092-CCT (Colour Temperature)
- Available CCT: 3000K, 5700K



Product Benefits


- · Visual comfort with maximum energy saving
- Minimilist design with optimum performance
- · Quick & simple installation.
- Flexible deployment options with a wide spectrum of applications.

Areas of Application

Building Facade, Textured surfaces, Building mounted focal points, Bridges, Archaeological monuments, etc.,

Accessory

- A separate IP67 rated connector supplied for a secure connection.
- Power supply unit of 24V dc required for the luminaire.
- The power supply units are also suitable for the operation of several LED luminaires. In this case total wattage of the LED luminaires must not exceed the wattage of power supply.



K-LiTE Linear Wall Washer





Technical Specifications General

ID : 3092 System Wattage : 12W LED Driver Non-Integral : Constant Voltage Input Voltage : 230-240Vac Frequency : 50-60 Hz Operating Voltage : 24Vdc Operating Temperature :-15°C~+50°C

Physical

Body : 6063 Aluminium Alloy Diffuser : Toughened Glass

Mounting : Surface Light Source

Light Source : NICHIA CRI (Ra) : ≥80 LED Colour Temperature : 3000K / 5700K

Driver


Power Supply : 24V Non Integral

Surge Protection Efficiency :3KV : 85%

Dimmable Options : 1-10V / PWM / Dali

Optical Performance

Beam Angle :30°/15°x60°



















Accessory



IP67 End Cap Connector Socket IP67 Extension cable - 1M



with Connector



M/F connector for power supply (0.5M cable)